




Folded Spacer

ex2-1258 / LETTER / PATTERN 1 / 1 of 2



Print the matching paper size at 100% / actual size.
Measure this line before cutting, folding or tracing.

Folded Spacer

ex2-1258 / LETTER / INSTRUCTIONS / 2 of 2

Two open-ended triangular paper prisms for testing a small display gap between lightweight paper surfaces.

DIMENSIONS

Each net: 75 x 68 mm.

Three equal 20 mm side panels plus an 8 mm joining tab.

Ideal triangle height: about 17.32 mm before material thickness.

MAKE A PLAIN-PAPER TRIAL

- 01 Cut both rectangular nets. Score the three long fold lines.
- 02 Fold the three equal side panels into a triangular section.
- 03 Join the 8 mm tab inside the first panel without flattening the triangle.
- 04 Let each prism dry with both ends open and its 75 mm length straight.
- 05 Use only as a trial display spacer under a light paper sample. Inspect for collapse before any further use.


MATERIALS

Ordinary paper for a first trial; scissors; ruler; a blunt scoring tool; a small amount of paper adhesive.

BEFORE YOU USE IT

No structural, cushioning, shock-protection or shipping-load rating.

Solid boundary = cut. Long dashes = fold/score. Dots = positioning guide. Pale grey = joining area. Keep tabs attached. Adult help is needed for internal cuts.



Print the matching paper size at 100% / actual size.
Measure this line before cutting, folding or tracing.