



Display-box divider study

gif-193 / A4 / Parts overview - NOT A CUTTING SHEET

USE THE FOLLOWING PATTERN SHEETS AT ACTUAL SIZE.

These miniature views identify the supplied patterns; they are deliberately reduced.




1. Pattern 1

1 pattern sheet supplied. Printed details are not cut lines unless explicitly marked.

Solid cut boundary / dashed score / shaded joining area. Read the full instructions.

Dry-fit the parts before gluing. Keep this overview beside the full-size pattern sheets.






Print at actual size / 100%. Disable fit-to-page.
Use the paper edition that matches the printer tray.

Display-box divider study

gif-193 / A4 / Pattern 1



Divider



Print at actual size / 100%. Disable fit-to-page.
Use the paper edition that matches the printer tray.

Display-box divider study

gif-193 / A4 / Instructions

PURPOSE

Display-box divider study. A positioning insert for expendable lightweight samples, not a protective bottle shipping divider.

DRAWING FACTS

- Two divider strips: 150 x 44 mm. Half-depth center slots form a nominal 150 x 150 mm cross.

MATERIALS

Plain paper for a first trial, a ruler, scissors and a blunt scoring tool; adult help for internal cuts.

HOW TO USE THESE PAGES

1. Cut both 150 x 44 mm strips and their half-depth center slits.
2. Hold one strip with its slit upward and the other with its slit downward. Slide the slits together until the strip top and bottom edges align.
3. Stand the crossed strips in an empty trial box. The cross spans 150 x 150 mm and creates four open corner areas; check the fit without bowing the strips.

LIMITS AND CHECKS

- A positioning insert for expendable lightweight samples, not a protective bottle shipping divider.
- Nominal drawing dimensions are not a tested usable-capacity, load, mailing, food-contact or archival specification.
- Do not place valuable, wet, hot or breakable items in an unreviewed paper prototype.
- Trial: Measure the 50 mm reference and at least two named panel dimensions.
- Trial: Assemble an empty plain-paper trial; record closure, seam, clearance and material behavior.



50 mm print check

Print at actual size / 100%. Disable fit-to-page.
Use the paper edition that matches the printer tray.